




Satellite Mobile Platform

Creating a model number



ESD Ground

(blank) - No ESD Ground

E - - - - Ground Lug and Drag Chain for use in EPA's Banana plugs

Lubricants

(blank) - Caster swivel bearings and Leveling jack screws lubricated with Krytox GPL 207

L2 - - - - Caster swivel bearings and Leveling jack screws lubricated with Braycote 601EF

Size

SMS - - - Mobile Stand

SM - - - - Small

MS - - - - Mid-Size

Push Bar

(blank) - No Push Bar

P1 - - - - Push Bar

Step

(blank) - No Step

S1 - - - - Removable Step (N/A for Mobile Stand size)

Proof Load Test

(blank) - No Proof Load Test

PLT - - - Standard Proof Load Test (includes deliverable report)

Caster

(blank) - Standard caster with brake & swivel lock

AC - - - - Air Caster System

C1 - - - - Standard Casters with 6" diameter standoffs to swap in the place of the casters

Leveling Jacks

(blank) - No Leveling Jacks

J0 - - - - Mounting Plates only for Jacks

J2 - - - - Jacks with removeable crank (MS only)

J5 - - - - Jacks with hex drive (SMS & SM only)

Towing Interface

(blank) - No Tow Bar

T1 - - - - Tow Bar

Mounting Interface

(blank) - Standard hole pattern

MLB - - - Motorized light band

ESPA - - - ESPA Ring

Example:

SMP - **SM** - **P1** - **T1** - **PLT**
 | | | | |
 Model type Small size Push Bar Tow Bar Standard Proof Load Test